This is the Revision A version of the <u>Compass8 Module</u>. The status of this project is that it has been <u>replaced</u> by the <u>Revision B</u> version.

Compass8 Module (Revision A)

Table of Contents

This document is also available in <u>PDF</u> format.

- <u>1. Introduction</u>
- <u>2. Programming</u>
- <u>3. Hardware</u>
 - ♦ <u>3.1 Circuit Schematic</u>
 - ♦ <u>3.2 Printed Circuit Board</u>
- <u>4. Software</u>
- <u>5. Issues</u>

1. Introduction

The Compass8 Module is a Module that can be used to connect to a <u>Dinsmore Instrument Company</u> digital compass. The compass can report the 8 bearings (N, NE, E, SE, S, SW, W, NW.)

A picture of the unpoplulated board is shown below:

I currently only have one of the digital compass modules and it has less than ideal behavior. My compass module works best in an envionment which has some vibration, otherwise the compass is prone to sticking and can be off by as much as 90 degrees. There is some significant hysterisis as rotation is changed; trying to steer a robot straight by aligning the robot with a bearing boundary (e.g. between N and NE) will not yield a very straight course due to this observed hysterisis effect. Of course, I may have a `lemon' module and other people might have different experiences with their modules. However, if all you want is basic compass bearing, the Dinsmore digital compass module does seem to meet that requirement at a very reasoable cost.

If you want a more accurate compass module, you might want to try the CMPS01 magnetic compass module available at: <u>Robot Electronics</u>.

2. Programming

The basic operation is to send a query to the Compass8 Module to read the 3 bits of bearing data.

The Compass8 Module supports <u>Module Interrupt Protocol</u>. The interrupt pending bit is set whenever the the formula:

B&M

is non-zero, where:

• B is the bearing expanded out into an 8-bit vector with only 1 bit turned on,

- M is the interrupt mask, and
- & is bit–wise AND

Once the interrupt pending bit is set, it must be explicitly cleared by the user.

The Compass8 Module supports both the standard<u>shared commands</u> and the<u>shared interrupt commands</u> in addition to the following commands:

| Command | Send/ Receive | Byte Value | | | | | | | | Dicoussion |
|---|------------------|------------|---|---|---|---|---|---|---|---|
| | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | Discussion |
| Read Bearing | Send | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Return bearing <i>bbb</i> (N=000, NE=001, E=010, SE=011, S=100, SW=101, W=110, NW=111) |
| | Receive | 0 | 0 | 0 | 0 | 0 | b | b | b | |
| Read Interrupt Mask | Send | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | Return interrupt mask mmmmmmmm (N, NE, E, SE, S, SW, W, NW) |
| | Receive | т | т | т | т | т | т | т | т | |
| Read Raw | Send | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | Return raw data <i>abcd</i> |
| | Receive | 0 | 0 | 0 | 0 | а | b | с | d | |
| Set Interrupt Mask | Send | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | Set interrupt mask to <i>mmmmmmmm</i> (N, NE, E, SE, S, SW, W, NW) |
| | Send | т | т | т | т | т | т | т | т | |
| Read Interrupt Bits | Send | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | Return the interrupt pending bit p and the interrupt enable bit e . |
| | Receive | 0 | 0 | 0 | 0 | 0 | 0 | е | р | |
| <u>Set Interrupt</u> <u>Commands</u> | Send | 1 | 1 | 1 | 1 | 0 | с | с | с | Set Interrupt Command ccc. |
| Shared Commands | Send | 1 | 1 | 1 | 1 | 1 | с | с | с | Execute Shared Command ccc. |

3. Hardware

The hardware consists of a circuit schematic and a printed circuit board.

3.1 Circuit Schematic

The schematic for the Compass8 Module is shown below:

Compass8 Module (Revision A)



The parts list kept in a separate file -- compass8.ptl.

3.2 Printed Circuit Board

The printed circuit board files are listed below:

compass8 back.png The solder side layer. compass8 front.png The component side layer. <u>compass8_artwork.png</u> The artwork layer. compass8.gbl The RS-272X "Gerber" back (solder side) layer. <u>compass8.gtl</u> The RS-272X "Gerber" top (component side) layer. compass8.gal The RS-272X "Gerber" artwork layer. <u>compass8.drl</u> The "Excellon" NC drill file. compass8.tol The "Excellon" tool rack file.

4. Software

The Compass8 software is available as one of:

<u>compass8.ucl</u> The μCL source file. <u>compass8.asm</u>

Compass8 Module (Revision A)

The resulting human readable PIC assembly file.

<u>compass8.lst</u>

The resulting human readable PIC listing file.

<u>compass8.hex</u>

The resulting Intel[®] Hex file.

5. Issues

The following fabrication issues came up:

- The holes for N1 are too large (size 3) and should be made smaller (size 2).
- Think about upgrading to a PIC12C505 and adding three or four indicator LED's; sort of like shaft2.

Copyright (c) 2001–2004 by Wayne C. Gramlich. All rights reserved.